

USER MANUAL MOMENTS COLLECTION



THANK YOU FOR HAVING SELECTED AN IMAGILIGHTS® MOMENTS® LAMP.

Carefully read this guide before using your lamp. Always use your lamp in conformity with the utilization precautions. Failure to do so will void any warranty. IMAGILIGHTS® disclaims any responsibility for incorrect use of the product or charger in combination with another product which could be defective, dangerous or inappropriate.

TECHNICAL INFORMATION

Light source	LED 24 - mini USB
Number of Leds	24
Led lifetime	+50.000 hours
Battery type	rechargeable Li-ion 3.7 V 18650 battery
Battery power	5200 mAh
Energy consumption	1.5 Watt
Remote	Infrared

MATERIAL

Metal: Anodized brushed aluminum

Plastics: PMMA + PC



FIRST USAGE PRECAUTIONS



To guarantee the maximum autonomy of your product, please conform to the first usage precautions:

- 1) Connect the charger
- 2) Fully charge your lamp's battery by placing the lamp on the charger for at least 8 hours. While the lamp is charging the light indicator on the charger will appear red. A green luminous indicator indicates the lamp is fully charged.

It is recommended to empty (discharge) the full capacity of the battery before recharging fully. The internal battery has a charge accumulator and will require 5 or 6 complete charges/discharges before reaching optimal charge capacity.

Your lamp automatically turns off when placed on its charger plate. This to protect the long life of the battery and to assure that charging and discharging is not done simultaneously.

Frequently re-tighten the lamp head by turning it firmer on the lamp base.



The flexible external cable of this charger cannot be replaced.
In case of damage the charger should be discarded.

LIGHT HOURS (APPROXIMATELY)

Charging time: 8 hours

High intensity in warm white: 18 hours

Low intensity in warm white: 76 hours

Color mix: 26 hours

Color fix: 34 hours

Candle effect: 34 hours





PRE-PROGRAMMED COLORS

- | | | |
|--------------------------|----------------------|-------------------|
| 1. Warm white | 9. Yellow | 17. Dark blue |
| 2. Galactic white | 10. White / Green | 18. Light pink |
| 3. Candle mode in yellow | 11. Light green | 19. Medium pink |
| 4. Candle mode in orange | 12. Dark green | 20. Dark pink |
| 5. Dark red | 13. Turquoise | 21. Salmon |
| 6. Light red | 14. Blue / Turquoise | 22. Light purple |
| 7. Light orange | 15. Blue / Green | 23. Dark purple |
| 8. Dark orange | 16. Purple / Blue | 24. Pink / Purple |





YOUR MOMENTS® LAMP




Battery indicator

-  66% - 100%
-  33% - 66%
-  5% - 33%
-  0% - 5%

Press color up for + 2sec. to switch your lamp ON or OFF

- ↑  COLOR UP: Choose between one of our 24 pre-programmed colors.
- ↓  COLOR DOWN: Choose between one of our 24 pre-programmed colors.
-  Start the 160.000 color mix mode 1 which will take approximately 14 minutes (= ultra slow), and will continue without interruption. To fix a color, press the same button again. To continue the cycle, press this same button again.
-  Shift through 4 different light intensity modes.

INFRARED REMOTE CONTROL



COLOR UP & DOWN: Choose between one of our 24 pre-programmed colors.

Start the 160.000 color mix mode 1 or 2 which will take approximately 14 minutes (= ultra slow), and will continue without interruption. To fix a color, press the same button again. To continue the cycle, press this same button again.


BRIGHTNESS: Shift through 4 different light intensity modes.

CANDLE MODE: Choose candle light mode 1 (yellow) or 2 (orange).


COLOR LOCK: Press this button multiple times while aiming at your lamps to disable the pushbuttons functions on the bottom of the lamps. To cancel the color lock function turn off your lamp with the remote or place it back on the charger.

The remote operates on one Lithium battery CR2025 3V

CHARGING POSSIBILITIES



The MOM 1 MINI CHARGER charges one single lamp and operates with the following adapter:
Input 100-240V AC~50/60 Hz - Output DC 6V 1A



One MOM 8 multi charger plate charges up to 8 lamps simultaneously. These can be stacked on top of each other. The MOM 8 MULTI CHARGER operates with the following adapter: Input 100-240V AC~50/60 Hz - Output DC 9V 5A

Your lamp automatically turns off when placed on its charger plate. This to protect the long life of the battery and to assure that charging and discharging is not done simultaneously. While the lamp is charging the indicator on the charger will appear red. A green luminous indicator indicates the lamp is fully charged.

Charger plates are not standard included when purchasing a table lamp
Lamp is useless without its specific prescribed IMAGILIGHTS® charger.



REPLACING SPARE PARTS


Every part of the MOMENTS lamp can be replaced when necessary. Please contact us at info@imagilight.com for more information.

To open the lamp first carefully turn the lamp's head off the lamp base. Remove the metal lamp base by pressing on the LED stick with your thumb while holding the metal lamp base.


CAUTION: Place your hand under the lamp base when dismantling the lamp. Failure to do so may result in the inside LED module to drop.




fase 1: turn off the lamp's head




fase 2: remove the metal lamp base



fase 3: loosen the screw of the battery door



fase 4: remove the battery door




fase 5: remove the battery
Push the battery down before pulling it out.
Attention: The device must be switched off
before removing the battery.

TROUBLESHOOTING

If your lamp falls and the top part of the head unclicks:

Firstly unscrew the opal diffusor from the lamp base before clicking the head back on. This to avoid damaging the USB led stick.



PACKAGE CONTENT

Lamp with integrated LED module.

CLEANING YOUR LAMP

It is recommended to clean your lamp with a soft humid cloth. Do not use any aggressive liquids or materials.

CAUTION

- MOMENTS® lamps are mainly intended for indoor use, however can be used outdoors (IP52 certified: rain & dust proof)
- The IP level cannot be maintained during charging. The device must be charged in an anhydrous place.
- Do not use the charger and lamp near a heat source or expose to fire.
- Do not try to open or dismount the lamp or charger to avoid any risk of electrical shock or altering its waterproofing.
Failure to comply will cancel your warranty.
- Do not connect the lamp to any other device.
- Do not try to charge the lamp with a charger other than the one supplied in your pack.
- Do not try to replace the battery with a battery other than the MOMENTS battery by IMAGILIGHTS®.
- Only use the USB led stick on your MOMENTS® lamp. Do not connect to any other device.
- Keep charger and lamp out of reach of young children.
- Do not store the lamp and charger in a humid area or outdoors.
- When storing your lamp, put it in its original box to avoid any damages or scratches.

RECYCLING

Do not throw this lamp away with your regular household garbage. Contact the appropriate service within your community to learn the best way to dispose of the device. Electrical products contain substances harmful to human health and the environment so must be adequately recycled. The battery must be safely removed before discarding the device.

LEGAL INFORMATION AND WARRANTY

IMAGILIGHTS® wireless lamps are covered by design registration, copyright and patent pending. All rights reserved. All shapes and models are registered. Patented LED module and patented charging possibilities. Any tampering with or repairing the unit voids the warranty. The unit is equipped with special labels to avoid tampering.

Manufacturer's warranty: 1 year.

COMPANY DATA

IMAGILIGHTS BVBA
Nijverheidslaan 62C
B-8540 Deerlijk
BELGIUM

Tel. +32 56 77 45 10
Email: info@imagilights.com
Website: www.imagilights.com